



1

**FLEX HARDWARE BUSHING KIT**

- KIT#: K0598
- 170-7216 Top Bushing
- 170-7217 Bottom Flange Bushing
- 170-7282 1" Flat Washer
- 170-7283 1/8" Roll Pin

QTY: \_\_\_\_\_

1

**FLEX HARDWARE BASE ASSEMBLY KIT**

- KIT#: K0599
- 170-7216 Top Bushing
- 170-7217 Bottom Flange Bushing
- 170-7282 1" Flat Washer
- 170-7283 1/8" Roll Pin
- 170-7215 Base Bracket
- 170-7200 Bagged Fasteners
- 170-7253 3/8" Lag Screw (4)

QTY: \_\_\_\_\_

1

**FLEX HARDWARE ARM ASSEMBLY**

Replacement arm assemblies are only available by service order due to custom sizing. Arms are only sold as part of the assembly.

1

**FLEX HARDWARE STANDOFF BRACKET KIT**

- KIT#: K0596
- 170-7212 Standoff Bracket
- 170-7253 3/8" Hex Lag (3)
- 170-7200 Bagged Fasteners
- 11337.00 3/8" Hex Nuts (4)

QTY: \_\_\_\_\_

1

**FLEX HARDWARE WELD PLATE KIT**

- KIT#: K0597
- 170-7256 Weld Plate
- 170-7200 Bagged Fasteners
- 11337.00 (4)

QTY: \_\_\_\_\_

**AIRGARD 100, 200, 240, 300,  
973, ECONOCLEAR  
REPLACEMENT KITS**



<b>SCALE:</b> N/A	<b>MATERIAL:</b> N/A			<b>ITEM NUMBER:</b>  N/A
<b>REV #:</b> 0	<b>DWG BY:</b> RTM	<b>DATE:</b> 1/6/2021	<b>ECN:</b> N/A	