

-HEADER MOUNT-

DOOR FULLY OPEN

-WALL MOUNT-

DWG # 2014 * DATE: 11-17-2000



HEADER

90° SWING **IMPORTANT** SEE NOTE 1

ADJUSTABLE

RUBBER PAD

(SEE DETAIL "A")

DOOR OPEN

AT 90°

JAMB

DETAIL "A"

FRONT VIEW

NOTES:

- 1. IF YOUR DOOR IS EQUIPPED WITH AN UPPER CANE BOLT BE SURE TO POSITON ADJUSTABLE TAB TO AVOID CONTACT WITH CANE BOLT.
- 2. IT MAY BE NECESSARY TO MOVE DOOR STOP UP APPROX. 1/4" FOR DOOR TO AVOID CONTACT WITH LOWER GUSSETT ON ADJUSTABLE TAB.

REMOVE BACKING FROM RUBBER PAD AND PLACE ON ADJUSTABLE TAB.

INSTALLATION STEPS 1. PLACE RUBBER PAD ON

90° DOOR STOP

HEADER

NOTE 2

5. RETURN DOOR STOP TO PROPER POSITION

(NOT SUPPLIED).

AND MOUNT WITH APPROPRIATE FASTENERS

TOP VIEW

- ADJUSTABLE TAB (SEE DETAIL "A"). 2. WITH THE DOOR FULLY OPEN AT
- 90°, POSITION DOOR STOP FLUSH WITH BOTTOM OF HEADER (SEE **NOTE 2 BEFORE MOVING TO** STEP 3).
- 3. SLIDE DOOR STOP ALONG HEADER UNTIL RUBBER PAD COMES IN CONTACT WITH THE DOOR.
- 4. WITH DOOR STOP IN POSITION, MARK HOLES.
- 5. REMOVE DOOR STOP AND DRILL CORRECT SIZE HOLES FOR FASTENERS BEING USED.
- 6. RETURN DOOR STOP TO PROPER POSITION AND MOUNT WITH APPROPRIATE FASTENERS (NOT SUPPLIED).

